


Slush Puppie Machinery and Equipment

Timer



To operate the defrost timer proceed as follows:

- 1) Set the time of day by rotating the dial clockwise (arrow A). Never rotate the timer counter clockwise as this would damage the internal mechanism. Align the current time of day with the arrow B on the timer face. This is a 24 hour timer showing both A.M. and P.M.
- 2) Program the defrost timer by pushing out on the tabs C that correspond to the hours desired to defrost. Each tab represent 15 minutes. A minimum of four to eight hours are required to defrost frozen beverage (depending on ambient condition).

Note: When all the tabs are pushed in the defrost function is OFF (the machine operates as if it were not equipped with Defrost Timer).